



FINO FIXING THE RUBBERS



Before you start: In most cases there is no need to fix rubbers, as most enclosures fit tightly around the tablet. Follow steps 1 & 2 to determine if rubbers are necessary.

- 1 Prepare the tablet holder the way it is going to be used: Portrait or landscape, with or without cable. Plug the cable in the tablet, in case you wish to powerfeed it.
- 2 Slide the tablet in the enclosure and check if it has room to move.
NO?: You are done! YES?: Continue with the following steps.
- 3 Remove strip and paste the rubbers centered, approximately 1cm from the long sides of the inner square.
- 4 Slide the tablet in from the side, while pressing it down onto the rubbers.
- 5 Make sure you can close the enclosure with the closing part.

